E-line Lightning Arrestor

Manual of Operation



(ALA01-A)

System Description	2
Connectors	3
Required Equipment	4
Installation	5
Technical Support	6

System Description

The E-line Lightning Arrestor (ALA01-A) provides extra protection for the receiver from electrical surges. This lightning arrestor is designed to limit the voltages and currents that could reach the electrical inputs of the receiver to a safe level, reducing the chance of damage to the receiver.



Connectors

- **1.** Four Electrode binding post connectors (*North and South*) and (*East and West*)
- 2. Four Receiver binding post connectors (North and South) and (East and West)
- **3.** Ground lug



Required Equipment

MT Receiver (x1) (to be protected) and it's accessories, including:

Electric sensor electrodes (x4), Ground electrode (x1) Hook-up wire (as required)

E-line lightning arrestor (x1) Hook-up wire (as required)


Ground Rod and hook-up wire (provided by the user)
* Use a large gauge wire to connect the ground rod
to the ground lug of the E-line lightning arrestor
(14 AWG - 1/0 wire gauges are supported)

Installation


- Connect the receiver to the Lightning Arrestor
 - **1.1.** Connect the lightning arrestor (ALA01-A) to the receiver, connect matching (North/South) and (East/West) binding post connectors with hook-up wire.
 - **1.2.** Connect the Ground rod to the Ground lug of the lightning arrestor (*ALA01-A*)

*The Lightning Arrestor must be installed at least 2 meters away from the receiver

2. Connect the ground electrode to the receiver



3. Connect the lightning arrestor (ALA01-A) to the Electric sensor electrodes.



Technical Support



Please check out the <u>FAQs</u>
https://phoenixgeophysics.freshdesk.com/
Or email us at: support@phoenix-geophysics.com